



Sanitary Silicone

Revision: 2/02/2024 Page 1 from 2

Technical data

Basis	Polysiloxane
Consistency	Stable paste
Curing system	Moisture curing
Skin formation* (23°C/50% R.H.)	Ca. 7 min
Curing speed * (23°C/50% R.H.)	Ca. 2 mm/24h
Hardness**	Ca. 15 ± 5 Shore A
Density	Ca. 1,01 g/ml (transp) Ca. 1,21 g/ml (colors)
Elastic recovery (ISO 7389)**	> 80 %
Maximum allowed distortion	20 %
Max. tension (ISO 37)**	Ca. 1,05 N/mm²
Elasticity modulus 100% (ISO 37)**	Ca. 0,30 N/mm²
Elongation at break (ISO 37)**	Ca. 700 %
Temperature resistance**	-60 °C → 120 °C
Application temperature	5 °C → 35 °C

^{*} These values may vary depending on environmental factors such as temperature, moisture, and type of substrates. ** This information relates to fully cured product.

Product description

Sanitary Silicone is a high quality, elastic, 1-component sealant based on silicones.

Properties

- Very easy to apply
- · Impervious to mould
- Very good adhesion on sanitary surfaces
- Permanently elastic after curing
- UV-resistant
- Very good resistance to ageing
- MEKO free

Applications

- For sealing of joints in sanitary and other moist rooms between e.g.. showers, bathtubs and (tiled) walls, between walls and washbasins, between floors and toilet.
- Joints in kitchens.
- · Joints in cold stores.

Packaging

Colour: transparent, white Packaging: 300 ml cartridge

Shelf life

12 months in unopened packaging in a cool and dry storage place at temperatures between +5°C and +25°C.

Substrates

Substrates: all usual building substrates, enamel, ceramic tiles, glass, wood, Galvanised metals, aluminium Nature: rigid, clean, dry, free of dust and grease.

Surface preparation: Porous surfaces should be primed with Primer 150. Prepare non-porous surfaces with a Soudal activator or cleaner (see Technical Data Sheet). There is no adhesion on PE, PP, PTFE (Teflon®) and bituminous substrates. We recommend a preliminary adhesion and compatibility test on every surface.

Joint dimensions

Min. width for joints: 5 mm Max. width for joints: 30 mm Min. depth for joints: 5 mm

Recommendation sealing jobs: joint width = 2

x joint depth.

Remark: This technical data sheet replaces al previous versions. The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. Since the design, the quality of the substrate and processing conditions are beyond our control, no liability under this publication is accepted. In every case it is recommended to carry out preliminary experiments. Soudal reserves the right to modify products without prior notice.

 Soudal NV
 Everdongenlaan 18 - 20
 B-2300 Turnhout, Belgium

 Tel: +32 (0)14-42.42.31
 Fax: +32 (0)14-42.65.14
 www.soudal.com





Sanitary Silicone

Revision: 2/02/2024 Page 2 from 2

Application method

Application method: With manual- or

pneumatic caulking gun.

Cleaning: Clean with White Spirit or Soudal Surface Cleaner immediately after use (before

curing).

Finishing: With a soapy solution or Soudal Finishing Solution before skinning. Repair: With the same material.

Health- and Safety Recommendations

Take the usual labour hygiene into account. Consult label and material safety data sheet for more information.

Dangerous. Respect the precautions for use.

Remarks

- Do not use on natural stones like marble. granite,...(staining). Use Soudal Silirub MA or Silirub+ S8800 for this application.
- A total absence of UV can cause a color change of the sealant.
- In an acid environment or in a dark room, a sealant can slightly turn yellow. Under the influence of sunlight it can turn back to its initial colour.
- Direct contact with the secondary sealing of insulating glass units (insulation) and the PVB-film of safety glass must be avoided.
- The sanitary formula should not replace regular cleaning of the joint. Excessive contamination, deposits or soap remainigs will stimulate the development of fungi.
- When finished with a finishing solution or soapy solution, make sure that the surfaces are not touched by this solution. This will cause the sealant not to adhere to that surface. Therefore we recommend to only dip the finishing tool in this solution.
- We strongly recommend not to apply the Finishing Solution in full sunlight as it will dry very fast in these circumstances.
- Do not use on polycarbonate. Use Silirub PC instead.
- Do not use in applications where continuous water immersion is possible.

- When using different reactive joint sealants, the first joint sealant must be completely hardened before the next one is applied.
- Contact with bitumen, tar or other plasticizer releasing materials such as EPDM, neoprene, butyl, etc. is to be avoided since it can give rise to discolouration and loss of adhesion.

Environmental clauses

Leed regulation:

Sanitary Silicone conforms to the requirements of LEED. Low -Emitting Materials: Adhesives and Sealants. SCAQMD rule 1168. Complies with USGBC LEED 2009 Credit 4.1: Low-Emitting Materials - Adhesives & Sealants concerning the VOC-content.

Liability

The content of this technical data sheet is the result of tests, monitoring and experience. It is general in nature and does not constitute any liability. It is the responsibility of the user to determine by his own tests whether the product is suitable for the application.

Remark: This technical data sheet replaces al previous versions. The directives contained in this documentation are the result of our experiments and of our experience and have been submitted in good faith. Because of the diversity of the materials and substrates and the great number of possible applications which are out of our control, we cannot accept any responsibility for the results obtained. Since the design, the quality of the substrate and processing conditions are beyond our control, no liability under this publication is accepted. In every case it is recommended to carry out preliminary experiments. Soudal reserves the right to modify products without prior notice.

Soudal NV Everdongenlaan 18 - 20 B-2300 Turnhout, Belgium Tel: +32 (0)14-42.42.31 Fax: +32 (0)14-42.65.14 www.soudal.com